

### Salted Caramel Chocolate Fat Bombs

½ cup – Almond Butter

½ cup – Coconut Oil

½ cup – Butter

20 drops liquid Stevia

1 tablespoon – Torani Sugar Free Salted Caramel Syrup

2 tablespoons – Unsweetened Cocoa Powder

Melt and mix all ingredients, pour in mini muffin tin or silicone pan and freeze overnight! Store in an airtight container in the freezer or fridge!

